BBB R KNDA XR/CRF80/100 F T A M C C T A C C

Installation tips:

- 1. Lay bike down (on clutch side) to ease tension on frame and motor.
- 2. Loosen ALL motor mount bolts.
- 3. Slide cradle into place.
- 4. Slide all three bolts through.
- 5. Torque to 25 foot pounds.
- 6. Recheck motor mount bolts periodically.

** Note – each frame and motor varies slightly. If it's been ridden hard it's most likely stretched some already and may take some manipulation to get the bolts through.

www.bbrmotorsports.com

HONDA XR/CRF80/100 FIGURE CIACLE

Installation tips:

- 1. Lay bike down (on clutch side) to ease tension on frame and motor.
- 2. Loosen ALL motor mount bolts.
- 3. Slide cradle into place.
- 4. Slide all three bolts through.
- 5. Torque to 25 foot pounds.
- 6. Recheck motor mount bolts periodically.

** Note – each frame and motor varies slightly. If it's been ridden hard it's most likely stretched some already and may take some manipulation to get the bolts through.



www.bbrmotorsports.com

BBBR HONDA VR/CRF80/100 Frame Cracle

Installation tips:

- 1. Lay bike down (on clutch side) to ease tension on frame and motor.
- 2. Loosen ALL motor mount bolts.
- 3. Slide cradle into place.
- 4. Slide all three bolts through.
- 5. Torque to 25 foot pounds.
- 6. Recheck motor mount bolts periodically.

** Note – each frame and motor varies slightly. If it's been ridden hard it's most likely stretched some already and may take some manipulation to get the bolts through.

