

TT-R90

PIPE INSTALLATION INSTRUCTIONS

Thank you for the purchase of this new BBR Exhaust System! Every effort has been made to develop the highest quality exhaust system possible.

- 1) Remove original exhaust system from bike. Refer to your owner's manual or a qualified mechanic if necessary.
- 2) We recommend installing a new O-ring in the exhaust port before installing your new exhaust system.
- 3) Slip the header pipe into the exhaust port and slide the exhaust flange onto the studs in the head. Install nuts (2) onto studs on the head. We recommend the use of blue Loctite (or similar thread adhesive). **DO NOT TIGHTEN NUTS AT THIS POINT.**
- 4) Install the top rear bolt (by the seat). Again, use of thread adhesive, such as blue Loctite, is recommended.
- 5) Tighten headpipe nuts. Now tighten the other mounting bolts. Check over all nuts and bolts for correct installation. Refer to your owner's manual for proper torque of all nuts and bolts.

Jetting recommendations: BBR recommends the use of stock jetting for all stock displacement engines. For big bore motors, check with the manufacturer of your kit.

For lower noise output, check out BBR's Quiet Exhaust

BBR

MOTORSPORTS (253) 631-8233 · www.bbrmotorsports.com



TT-R90

PIPE INSTALLATION INSTRUCTIONS

Thank you for the purchase of this new BBR Exhaust System! Every effort has been made to develop the highest quality exhaust system possible.

- 1) Remove original exhaust system from bike. Refer to your owner's manual or a qualified mechanic if necessary.
- 2) We recommend installing a new O-ring in the exhaust port before installing your new exhaust system.
- 3) Slip the header pipe into the exhaust port and slide the exhaust flange onto the studs in the head. Install nuts (2) onto studs on the head. We recommend the use of blue Loctite (or similar thread adhesive). **DO NOT TIGHTEN NUTS AT THIS POINT.**
- 4) Install the top rear bolt (by the seat). Again, use of thread adhesive, such as blue Loctite, is recommended.
- 5) Tighten headpipe nuts. Now tighten the other mounting bolts. Check over all nuts and bolts for correct installation. Refer to your owner's manual for proper torque of all nuts and bolts.

Jetting recommendations: BBR recommends the use of stock jetting for all stock displacement engines. For big bore motors, check with the manufacturer of your kit.

For lower noise output, check out BBR's Quiet Exhaust

BBR

MOTORSPORTS (253) 631-8233 · www.bbrmotorsports.com



TT-R90

PIPE INSTALLATION INSTRUCTIONS

Thank you for the purchase of this new BBR Exhaust System! Every effort has been made to develop the highest quality exhaust system possible.

- 1) Remove original exhaust system from bike. Refer to your owner's manual or a qualified mechanic if necessary.
- 2) We recommend installing a new O-ring in the exhaust port before installing your new exhaust system.
- 3) Slip the header pipe into the exhaust port and slide the exhaust flange onto the studs in the head. Install nuts (2) onto studs on the head. We recommend the use of blue Loctite (or similar thread adhesive). **DO NOT TIGHTEN NUTS AT THIS POINT.**
- 4) Install the top rear bolt (by the seat). Again, use of thread adhesive, such as blue Loctite, is recommended.
- 5) Tighten headpipe nuts. Now tighten the other mounting bolts. Check over all nuts and bolts for correct installation. Refer to your owner's manual for proper torque of all nuts and bolts.

Jetting recommendations: BBR recommends the use of stock jetting for all stock displacement engines. For big bore motors, check with the manufacturer of your kit.

For lower noise output, check out BBR's Quiet Exhaust

BBR

MOTORSPORTS (253) 631-8233 · www.bbrmotorsports.com



TT-R90

PIPE INSTALLATION INSTRUCTIONS

Thank you for the purchase of this new BBR Exhaust System! Every effort has been made to develop the highest quality exhaust system possible.

- 1) Remove original exhaust system from bike. Refer to your owner's manual or a qualified mechanic if necessary.
- 2) We recommend installing a new O-ring in the exhaust port before installing your new exhaust system.
- 3) Slip the header pipe into the exhaust port and slide the exhaust flange onto the studs in the head. Install nuts (2) onto studs on the head. We recommend the use of blue Loctite (or similar thread adhesive). **DO NOT TIGHTEN NUTS AT THIS POINT.**
- 4) Install the top rear bolt (by the seat). Again, use of thread adhesive, such as blue Loctite, is recommended.
- 5) Tighten headpipe nuts. Now tighten the other mounting bolts. Check over all nuts and bolts for correct installation. Refer to your owner's manual for proper torque of all nuts and bolts.

Jetting recommendations: BBR recommends the use of stock jetting for all stock displacement engines. For big bore motors, check with the manufacturer of your kit.

For lower noise output, check out BBR's Quiet Exhaust

BBR

MOTORSPORTS (253) 631-8233 · www.bbrmotorsports.com

